

User manual

Process controller Series RE 3070



Table of contents	page	page	
Wichtiger Hinweis	2	5 Displays	53
1 Introduction	3	6 Commands	54
2 Installation	4	6.1 Commands from keyboard	55
2.1 Description	4	6.2 Commands from digital inputs	58
2.2 Operating conditions	6	6.3 Commands from serial communication (please, refer the addendum on the serial communication)	
2.3 Installation	7		
3 Electrical connections	8	7 Setpoint programmer (optional)	59
3.1 Termination unit	8	7.1 Program organisation	59
3.2 Cabling layout	9	7.2 Operating conditions	60
3.3 Example of wiring diagram	10	7.3 Parameterisation – Program Menu	62
4 Operations	20	7.4 Program status displaying	64
4.1 Keys functions and display	20	7.5 Run/stop of a program	65
4.2 Data setting	22	8 Technical specifications	69
4.3 Configuration	23	9 Wiring diagrams	74
4.4 Parameterisation	32		
4.5 Parameters	40		
4.6 Access levels	50		

NOTES ON ELECTRIC SAFETY AND ELECTROMAGNETIC COMPATIBILITY



Please, read carefully these instructions before proceeding with the installation of the controller. Class II instrument, for indoor use only.

This controller has been designed with compliance to:
Regulations on electrical apparatus (appliance, systems and installations) according to the European community directive 73/23/EEC amended by the European Community directive 93/68/EEC and the Regulations on the essential protection requirements in electrical apparatus EN61010-1 : 93 + A2:95.

Regulations on Electromagnetic Compatibility according to the European Community directive n° 89/336/EEC, amended by the European Community directive n° 92/31/EEC, 93/68/EEC, 98/13/EEC and the following regulations:

- Regulations on RF emissions EN61000-6-3 : 2001 residential environments
EN61000-6-4 : 2001 industrial environments
- Regulation on RF immunity: EN61000-6-2 : 2001 industrial equipment in a system

It is important to understand that it's responsibility of the installer to ensure the compliance of the regulations on safety requirements and EMC.

Repairs: this device has no user serviceable parts and requires special equipment and specialised engineers. Therefore, a repair can be hardly carried on directly by the user. For this purpose, the manufacturer provides technical assistance and the repair service for its Customers. Please, contact your nearest Agent for further information.

All the information and warnings about safety and electromagnetic compatibility are marked with the sign, at the side of the note.


1. Introduction

Powerful features and a wide range of functionalities

Congratulations for having chosen these universal controllers. They are the best result of our experience in designing and manufacturing of smart, powerful and high reliable controllers.


The process controllers of the X5 series have been designed for the industrial environment, are provided with a complete set of functions, as a true universal instrument.

They can be used as Controllers-Programmers with 4 Setpoint profiles of 16 segments.



2 Installation


Installation must only be carried out by qualified personnel.

Before proceeding with the installation of this controller, follow the instructions illustrated in this manual and, particularly the installation precautions marked with the  symbol, related to the European Community directive on electrical protection and electromagnetic compatibility.




To prevent hands or metal touching parts that may be electrically live, the controllers must be installed in an enclosure and/or in a cubicle.


2.1 Allgemeine Beschreibung



2.1.1 Dimensional details





2.1.2 Panel cut-out






2.2 Environmental ratings



Operating conditions

 2000	Altitude up to 2000 m
 °C	Temperature 0...50°C [1]
%Rh	Relative humidity 5...95 % non-condensing

Special conditions

Special conditions	Suggestions
 2000	Altitude > 2000 m Use 24Vac supply version
 °C	Temperature > 50°C Use forced air ventilation
%Rh	Humidity > 95 % Warm up
	Conducting atmosphere Use filter

Forbidden Conditions

	Corrosive atmosphere
	Explosive atmosphere


2.3 Panel mounting (1)

2.3.1 Insert the instrument

- 1 Prepare panel cut-out;
- 2 Check front panel gasket position;
- 3 Insert the instrument through the cut-out.


UL note

(1) For Use on a Flat Surface of a Type 2 and Type 3 'raintight' Enclosure.




2.3.2 Installation securing

- 1 Prepare panel cut-out;
- 2 Check front panel gasket position;
- 3 Insert the instrument through the cut-out.



2.3.3 Clamps removing

- 1 Insert the screwdriver in the clips of the clamps;
- 2 Rotate the screwdriver.




2.3.4 Instrument unplugging




- 1 Push and
- 2 Pull to remove the instrument.

Electrostatic discharges can damage the instrument.




Before removing the instrument the operator must discharge himself to ground.




3. Electrical connections


3.1 Termination unit











UL note
(1) Use 60/70 °C copper (Cu) conductor only.




Rear terminal cover



-  35 screw terminals M3
-  Option terminals
-  Holding screw 0.5 Nm
-  Positive screw-driver PH1
-  Negative screw-driver 0.8 x 4 mm
- Terminals**
-  Pin connector \varnothing 1.4 mm - 0.055 in max.
-  Fork-shape AMP 165004 \varnothing 5.5 mm - 0.21 in
-  Stripped wire L 5.5 mm - 0.21 in


Precautions

Despite the fact that the instrument has been designed to work in an harsh and noisy environmental (level IV of the industrial standard IEC 801-4), it is recommended to follow the following suggestions.

 All the wiring must comply with the local regulations. The supply wiring should be routed away from the power cables. Avoid to use electromagnetic contactors, power Relays and high power motors nearby. Avoid power units nearby, especially if controlled in phase angle.

Keep the low level sensor input wires away from the power lines and the output cables. If this is not achievable, use shielded cables on the sensor input, with the shield connected to earth.


3.2. Suggested wires routing



- A** = Supply
- B** = Outputs
- C** = Analog inputs
- D** = Analogue output
- E** = Digital input
Serial Comm.s

3.3. Example of wiring diagram

(Valve control)



Notes:

- 1) Make sure that the power supply voltage is the same indicated on the instrument.
- 2) Switch on the power supply only after that all the electrical connections have been completed.
- 3) In accordance with the safety regulations, the power supply switch shall bring the identification of the relevant instrument. The power supply switch shall be easily accessible from the operator.
- 4) The instrument is PTC protected. In case of failure it is suggested to return the instrument to the manufacturer for repair.
- 5) To protect the instrument internal circuits use:
 - 2 AT fuse for Relay outputs (220 Vac)
 - 4 AT fuse for Relay outputs (110 Vac)
 - 1 AT fuse for Triac outputs
- 6) Relay contacts are already protected with varistors.

Only in case of 24 Vac inductive loads, use model A51-065-30D7 varistors (on request)

3.3.1 Power supply


Switching power supply with multiple isolation and PTC protection.

• Standard version:

Nominal voltage:
100... 240Vac (-15...+10%);
Frequency 50/60Hz.

• Low Voltage version:


Nominal voltage:
24Vac (-25...+12%);
Frequency 50/60Hz
or 24Vdc (-15...+25%);
Power consumption 5W max.



3.3.2 PV control input


A L-J-K-S-R-T-B-N-E-W thermocouple type

- Connect the wires with the polarity as shown;
- Use always compensation cable of the correct type for the thermocouple used;
- The shield, if present, must be connected to a proper earth.




B For Pt100 resistance thermometer

- If a 3 wires system is used, use always cables of the same diameter (1mm² min.), maximum line resistance 20 Ω/line.
- When using a 2 wires system, use always cables of the same section (1.5mm² min.) and put a jumper between terminals 11 and 12



C For ΔT (2x RTD Pt100) Special

- ⚠ When the distance between the controller and the sensor is 15m using a cable of 1.5mm² section, produces an error on the measure of 1 °C.




R1 + R2 must be <320Ω

3.3.2 PV control input




C For mA, mV

Input resistance = 30Ω per mA;
 Input resistance > $10M\Omega$ per mV;
 Input resistance = $10k\Omega$ per Volt;




C1 With 2 wires transducer



C2 With 3 wires transducer

Note:

(1) Auxiliary power supply for external transmitter 24Vdc $\pm 20\%$ /30mA max without short circuit protection.




3.3.3 PV control input – IN2 Frequency input



Using the frequency input (IN2), the IN1 input is not yet available

- Low level: 0...2Volt / 0.5mA max.
- High level: 3...24Volt / ~ 0 mA max..
- Frequency range: 0...2kHz / 0...20kHz, selectable in configuration mode;
- Use sensors with an NPN output or a clean contact.



3.3.4 Auxiliary input




A - From Remote Setpoint

Current 0/4...20mA;
 Input resistance = 30Ω .
 Voltage 1...5V, 0...5V, 0...10V;
 Input resistance = $300k\Omega$.

Not available with frequency input


B - From Potentiometer

for the measure of the position of the motor or the valve.



3.3.5 Digital input

- The input is active when the logic state is ON, corresponding to the contact closed.
- The input is inactive when the logic state is OFF, corresponding to the contact open.



3.3.6 OP2 - OP3 - OP4 - OP5 - OP6 output (option)

The functionality associated to each of the OP1, OP2, OP4, OP5 and OP6 output is defined during the configuration of the instrument.


The suggested combinations are:

		Control outputs		Alarms				Retransmission	
		Main (Heat)	Secondary (Cool)	AL1	AL2	AL3	AL4	PV / SP / OP	
A	Single action	OP1			OP2	OP3	OP4	OP5	OP6
B	Split range	OP5		OP1	OP2	OP3	OP4		OP6
C	Double action	OP1	OP2			OP3	OP4	OP5	OP6
D	Double action	OP1	OP5		OP2	OP3	OP4		OP6
E		OP5	OP2	OP1		OP3	OP4		OP6
F		OP5	OP6		OP2	OP3	OP4		
G	Valve drive	OP1 ▲	OP2 ▼			OP3	OP4	OP5	OP6


where:

OP1 - OP2	Relay or Triac output
OP3 - OP4	Relay outputs
OP5 - OP6	Analogue/ digital control or retransmission outputs


3.3.6-A Single action relay (TRIAC) control output





3.3.6-B1 Single action SSR drive control output




3.3.6-B2 Single action analogue output




3.3.6-C Double action relay (TRIAC) / relay (TRIAC) control output





3.3.6-D1 Double action relay (TRIAC) / SSR drive control output





3.3.6-D2 Heat / cool control output relay (TRIAC) / Analogue





3.3.6-E1 Double action control output / relay (TRIAC)



3.3.6-E2 Heat / cool control output analogue / relay (TRIAC)



3.3.6-F1 Double action control output digital / digital



Notes for pages 15 - 16 - 17

OP1 - OP2 Relay output

- SPST Relay N.O., 2A/250 Vac (4A/120Vac) for resistive load,
- Fuse 2AT at 250V, 4AT at 110V.

OP1 - OP2 Triac output

- N.O. contact for resistive load of up to 1A/250 Vac max.
- Fuse 1A T

Isolated digital outputs OP5-OP6



- 0...24Vdc, $\pm 20\%$, 30 mA max.

Isolated analogue outputs OP5-OP6



- 0/4...20mA, 750 Ω / 15V max.
- 0/1...5V, 0...10V, 500 Ω / 20mA max.

**(1) Varistor for inductive load
24Vac only**



3.3.6-F2 Double action control output digital/analogue



3.3.6-F3 Double action control output analogue/digital




3.3.6-F4 Double action control output analogue/ analogue




3.3.6-G Motor positioner output relay (TRIAC)/ relay (TRIAC)


Valve drive PID without potentiometer
3 pole output with N.O. contacts
(increase, decrease, stop)




3.3.7 OP1-2-3-4 Alarm output



The relay/triac output OP1, OP2, can be used as alarm outputs only if they are not used as control outputs.



3.3.8 OP5 und OP6 (option) analogue control outputs




OP5 and OP6 outputs can be configured for control action or PV/SP/OP retransmission:


- Galvanic isolation 500Vac/1 min;
- 0/4...20mA, 750Ω / 15Vdc max.
- 0/1...5V, 0...10V, 500Ω / 20mA max..

Notes:
(1) Varistor for inductive load 24Vac only


3.3.9 Serial communications (Option)



- Galvanic isolation 500Vac/1 min; Compliance to the EIA RS485 standard for Modbus/Jbus;
- Termination setting dip switches.




3.3.10 Profibus DP (option)



- Galvanic isolation 500 Vac/1 min
- Compliance to the EIA RS485 standard for PROFIBUS DP;
- Connecting cable: twisted pair cable as per PROFIBUS specifications (e.g. Belden B3079A);
- Max. length: 100 m at 12 Mb/s

Termination resistors 220Ω and 390Ω (1/4 W, ±5%) for external mounting on the initial and ending PROFIBUS stations only.




X5	D-SUB 9 poles	Signal	Description according to PROFIBUS specifications
1	3	RxD/TxD-P (DP)	Receive data/transmission data plus
2	8	RxD/TxD-N (DN)	Receive data/transmission data negative
3	5	DGND (DG)	Data transmission potential (ground to 5V)
4	6	VP (VP)	Supply voltage of the terminating resistance-P, (P5V)

Detailed information concerning wiring and cables can be found on the PROFIBUS Product Guide or on Internet at:

<http://www.profibus.com/online/list>

4. Operation

4.1.1 Key functions and displays in operator




4.1.2 Functions and display in programming mode

The parameter setting procedure has a timeout. If no keys are pressed for, at least, 30 seconds, the controller switches back, automatically, to the operator mode.

After having selected the parameter or the code, press and to display or modify the value.

The value is entered when the next parameter is selected, by pressing the key. Pressing the back key or after 30 seconds from the last modification, the value doesn't change.

From every parameter, pressing the key, the controller switches to the operator mode.



4.2 Parameter settings


4.2.1 Numeric entry

(i.e. the modification of the Setpoint value from 275.0 to 240.0)

Press or momentarily to change the value of 1 unit every push. Continued pressing of or changes the value, at rate that doubles every second. Releasing the button the rate of change decreases. In any case the change of the value stops when it has reached the max/min limit set for the parameter.

In case of Setpoint modification: press or once to display the local Setpoint instead of working Setpoint.


To evidence this change the display flashes once. Then the Setpoint can be modified



4.2.2 Mnemonic codes setting


(e.g. configuration see page 24)

Press the or to display the next or previous mnemonic for the selected parameter.




Continued pressing of or will display further mnemonics at a rate of one mnemonic every 0.5 s. The mnemonic displayed at the time the next parameter is selected, is the one stored in the parameter.

4.3 Configuration procedure



4.3.1 Inputs configuration




Value	Description	InP.	
tc.d	0...600°C	32...1112°F	
tc.b	0...1200°C	32...2192°F	
tc.l	0...600°C	32...1112°F	
tc.s	0...1600°C	32...2912°F	
tc.r	0...1600°C	32...2912°F	
tc.t	-200...400°C	-328...752°F	
tc.b	0...1800°C	32...3272°F	
tc.n	0...1200°C [1]	32...2192°F	
tc.n1	0...1100°C [2]	32...2012°F	
tc.u3	0...2000°C	32...3632°F	
tc.u5	0...2000°C	32...3632°F	
tc.e	0...600°C	32...1112°F	
cu5t	Custom range on request		
red1	-200...600°C	-328...1112°F	
red2	-99.9...300.0°C	-99.9...572.0°F	
delt	-50.0...50.0°C	-58.0...122.0°F	
m50	0...50 mV	Engineering units	
m300	0...300 mV		
0-5	0...5 Volt		
1-5	1...5 Volt		
0-10	0...10 Volt		
0-20	0...20 mA		
4-20	4...20 mA		
Fr9L	0...2.000 Hz		Frequency (option)
Fr9H	0...20.000 Hz		

Value	Description	Unit
none	None	
c	Degree centigrade	
F	Degree Fahrenheit	
mA	mA	
mV	mV	
V	Volt	
bar	bar	
PSI	PSI	
Rh	Rh	
Ph	Ph	
Hz	Hertz	

Notes:
 [1] NiChroSil-NiSil thermocouple.
 [2] Ni-Mo thermocouple.


4.3.2 Setpoint configuration



Value	Description	S.P.ty
Loc	Local only	
rPn	Remote only	
L-r	Local/remote only	
Loc.t	Local - trim	
rPn.t	Remote - trim	
Prpg	Programmed (option)	

Value	Description	rS.in
0-5	0...5 Volt	
1-5	1...5 Volt	
0-10	0...10 Volt	
0-20	0...20 mA	
4-20	4...20 mA	

4.3.2 Output configuration



(1) Nicht verfügbar bei Programmgeber (S.P.ty = Prog)

Value	Description	Control
OFF.rP	Reverse action	On - Off
OFF.d	Direct action	
P.idd	Direct action	PID
P.idr	Reverse action	
U.d ir	Direct action	Modul. valves
U.rPU	Reverse action	
H.C.Ln	Linear	Heat/ Cool
H.C.Ol	Oil charac.	
H.C.H2	Water charac.	Split range [1]
S.PL.1	Direct-Direct	
S.PL.2	Direct-Reverse	
S.PL.3	Reverse-Reverse	
S.PL.4	Reverse-Direct	

[1] Nicht verfügbar bei Programmgeber (S.P.ty = Prog)

Value	Description	N.C.OP
OFF	Not used	
OP.1	Relay / Triac	Digital signal
L.o.g	Digital	Digital signal
0-5	0...5 Volt	DC signal
1-5	1...5 Volt	
0-10	0...10 Volt	
0-20	0...20 mA	
4-20	4...20 mA	

Value	Description	S.C.OP
OFF	Not used	
OP.2	Relay / Triac	Digital signal
L.o.g	Digital	Digital signal
0-5	0...5 Volt	DC signal
1-5	1...5 Volt	
0-10	0...10 Volt	
0-20	0...20 mA	
4-20	4...20 mA	

Value	Description	Ort.1	Ort.2
0-5	0...5 Volt		
1-5	1...5 Volt		
0-10	0...10 Volt		
0-20	0...20 mA		
4-20	4...20 mA		

Retransmission

When OP5 and OP6 outputs are not configured as control output, they can retransmit the PV, SP or OP linearised value.

Retransmitted signals

rt.1 Main output *nonP/P.U/SP.*

rt.2 Secondary output

Output range

Ort.1 *0-5/1-5/0-10*
0-20/4-20

Ort.2

The following parameters define the low and high range.

Retransmission high range

rt.H1

rt.H2


Retransmission high range

rt.H1

rt.H2


Example:

- T/C S: range 0...1600°C;
- Output range, 4...20 mA;
- Retransmitted signal PV on 800...1200°C range.



With **rt.L1** greater than **rt.H1** it is possible to obtain a reverse scale.


4.3.4 Digital inputs configuration



Tab. 10 Digital Inputs Functions

Value	Description	IL 1	IL 2	IL 3
0FF	Not used			
L-r	Local/Remote			
ANdN	Auto/Man			
S.P. 1	1 st stored Setpoint			
S.P. 2	2 nd stored Setpoint			
S.P. 3	3 rd stored Setpoint			
LPb.1	Keyboard lock			
SLa.1	S.P. slope disable			
HPU	Measure hold			
FDUt	Output forcing mode			
Pr.9.1	1 st program			up to 3
Pr.9.2	2 nd program			
Pr.9.3	3 rd program			
Pr.9.4	4 th program			
r.-H	Program Run/Stop			
rSt	Program reset			
blcK	Reset blocking			
nPHt	Next segment			
accK	Alarm acknowledge			

4.3.5 Alarmkonfiguration



[1] OP1 and OP2 outputs can be used as alarm outputs if they are not used as control outputs.

[2] OP3 and OP4 can be related to the program (if option installed).

Tab. 11 Alarm type

Value	Description	AL 1	AL 2	AL 3	AL 4
0FF	Not used or used by the program (AL3/AL4)				
F5H	Active High				Absolute (input)
F5L	Active Low				(input)
dPUH	Active High				Deviation (input)
dPUL	Active Low				(input)
bnd i	Active In				Band (input)
bndo	Active Out				(input)
OPH	Active High				Absolute (output)
OPL	Active Low				(output)
Lbd	Loop break alarm (AL1 only)				

Hinweis:
OP.H, OP.L absolute alarm n output value (full scale) can be associated only to AL2, AL3 and AL4

4.3.6 AL1, AL2, AL3, AL4 Alarms configuration

It is possible to configure up to 4 alarms: AL1, AL2, AL3, AL4 (see page 28/29) selecting, for each of them:




- A** the type and the operating condition of the alarm (table 11 page 29)
- B** the functionality of the alarm acknowledge (latching) `Ltch`
- C** the start-up disabling (blocking) `blac`
- D** alarm inhibition on sensor break
- E** the physical output of the alarm

`OP1` `OP2` `OP3` `OP4`

The outputs can be used for alarms if they are not used as control outputs (see par. 3.3.7 page 18).


It is possible to route up to 4 alarm to a single output (OR of the alarms).

(A) Operating conditions





(B) Alarm acknowledge function (latching)

The alarm, once occurred, is presented on the display until the time of acknowledge. The acknowledge operation consists in pressing any key.




After this operation, the alarm leaves the alarm state only when the alarm condition is no longer present.

(C) Start-up disabling (blocking)



(D) Alarm disabling at sensor break

For those alarm that are configured to be different than LBA, is possible to set the parameter `danb` (disable on break).




Set:

- no To maintain the alarm status when a sensor break is detected.
- yes To disable the alarm intervention when a sensor break is detected. Once the sensor has been changed, the alarms that were active before the sensor break are activated again.


Loop break alarm LBA

When the controller connection to the sensor is discontinued or other faults are detected in the control loop, the AL1 alarm becomes active, after a predefined time of 1... 9999 s, from the detection of the failure (see page 35). When a sensor failure occurs, the LBA intervention is immediate. The alarm state ceases when the fault condition is no longer present.




⚠ In case of ON-OFF control, the LBA alarm is not active.


4.4 Parameterisation – main menu



4.4.1 Parameterisation – setpoint menu



4.4.2 Parametrierung – Alarm-Menü




(1) A code, specifying the number and the alarm type that has been configured (see page 29), is displayed. At this point, the user must enter the threshold value, according to the following table.


Type and adj. value	Mode	Number and Parameter
Absolute full scale on input	Active high	-FSH
	Active low	-FSL
Deviation full scale on input	Active high	-dPH
	Active low	-dPL
Band full scale on input	Active in band	-bn1
	Active out of band	-bno
Absolute full scale on output	Active high	-OPH
	Active low	-OPL
L.B.A. 1...9999s	Active high	-Lb2

Hinweis: OPH, OPL Alarm Ausgangswert kann nur AL2, AL3 und AL4 zugeordnet werden.

4.4.3 Parameterisation - PID menu (not shown for ON-OFF control action)




4.4.4 Parameterisation – Tuning menu (not shown for ON-OFF control action)




[1] These values are not automatically stored on the PID menu parameters *P.b.*, *t.i.*, *t.d.*


4.4.5 Parameterisation – input menu



4.4.6 Parameterisation – output menu



4.4.7 Parameterisation – serial communication menu



4.5 Parameters

For a simpler use of the controller, its parameters have been organised in menu, according to their functionality area.

4.5.1 Sollwert-Menü

S.P. L Setpoint low limit
S.P. H Setpoint high limit

High and low limit of the Setpoint SP. The minimum span (S.P.L - S.P.H) must be greater than 100 digit.


SL. u Setpoint ramp up
SL. d Setpoint ramp down

This parameter specifies the maximum rate of change of the Setpoint. Adjustable in digit/s, digit/min and digit/hour (see page 25)

When the parameter is (OFF) this function is disabled and the new Setpoint is reached immediately after being entered.

Otherwise, the Setpoint value is reached according to the configured rate of change. The new Setpoint value is called "Target Setpoint". It can be displayed by means the parameter **E.S.P.** (see procedure at page 53).

When Remote Setpoint is configured, we suggest to disable **SL. u** and **SL. d** parameters **OFF**.



S.P. 1 1st stored Setpoint
S.P. 2 2nd stored Setpoint
S.P. 3 3th stored Setpoint

Values of the three Setpoints, that are activated by mean of logic inputs, communication parameters, and keyboard. The Setpoint active is indicated by the **S1**, **S2** or **S3** green led. oder angezeigt.

See also page 56.

r.S.SL Remote Setpoint Slope enable

To enable or disable slopes when the remote Setpoint is active.

S.P.tr Stored Setpoint tracking

(see chapter 4.3.2 at page 25) Two different operation mode can be set: A- Stand-by mode **no** The memorised Setpoint is active until its command is active too. Then the controller goes back to the Local Setpoint which becomes the operating one.

B- Tracking mode **yes**
 Once the memorised Setpoint is active, it remains operating also when its command is not active anymore.

The previous Local Setpoint value will be lost.


rt 10 Remote Setpoint Ratio

Ratio is the coeff. which defines the remote Setpoint span with respect to the input span.

b 125 Basissollwert

Bias defines the starting point of analogue Remote Setpoint in eng. units corresponding to the low limit (current or voltage) of the remote signal.

Remote Setpoint Bias and Ratio



PV = Process variable
 LR = PV low limit
 HR = PV high limit
 SR = Remote Setpoint
 a (a') = SR starting point
 b (b') = SR ending point

If SR starting point is lower than the ending point, both expressed in engineering units:

$$b_{\text{SR}} = \text{starting point} = a$$

$$r_{\text{SR}} = \frac{b - a}{\text{HR} - \text{LR}}$$

E.g.: $b_{\text{SR}} = 20$

$$r_{\text{SR}} = \frac{100 - 20}{600 - (-200)} = \frac{80}{800} = 0.1$$

If SR starting point is higher than the ending point, both expressed in engineering units

$$b_{\text{SR}} = \text{starting point} = a'$$

$$r_{\text{SR}} = \frac{b' - a'}{\text{HR} - \text{LR}}$$

E.g.: $b_{\text{SR}} = 100$

$$r_{\text{SR}} = \frac{20 - 100}{600 - (-200)} = \frac{-80}{800} = -0.1$$

Working Setpoint (SP) as combination of Local Setpoint (SL) and remote signal

Setpoint Loc.t (table 3, page 25)

$$\text{SP} = \text{REM} + (r_{\text{SR}} \cdot \text{SL}) + b_{\text{SR}}$$

SIGN = Remote signal %

SPAN = HR-LR

$$\text{REM} = \frac{\text{SIGN} \cdot \text{SPAN}}{100}$$

E.g.: Local Setpoint (SL) with an external Trim with multiplying coefficient of 1/10:

Setpoint type = Local

$$r_{\text{SR}} = 0.1; b_{\text{SR}} = 0$$

Remote Setpoint (SR) with an internal Trim with multiplying coefficient of 1/5:

Setpoint type = Remote

$$r_{\text{SR}} = 0.2; b_{\text{SR}} = 0$$

Remote Setpoint range equal to the Input range:

Setpoint type = Local

$$r_{\text{SR}} = 1; b_{\text{SR}} = \text{LR}$$

$$SL = 0$$

Remote Setpoint range equal to the Input range:

Setpoint type = Local

$$r_{\text{SR}} = 1; b_{\text{SR}} = \text{LR}$$

$$SL = 0$$

4.5.2 Alarm menu

(see also page 30 and 31)


69.u

Asymmetric upper alarm hysteresis

69.d

Asymmetric lower alarm hysteresis

Example with high absolute alarm



The parameter can be set between 0 and 5% of the configured Span and set in Engineering units. e.g.
 Range = -200...600°C
 Span = 800°C Max.
 Hysteresis = 5% 800° = 40°C

For symmetrical hysteresis set

$$69.d = 69.u$$

EF1

Alarm delay

Delay time for alarm activation.

OFF: alarm activated immediately

1...9999: alarm activated only if the condition persists for the set time

4.5.3 PID menu

Not present with On-Off main output.

P.b.

Proportional Band

P.b.C

Cool Proportional Band

This parameter specifies the proportional band coefficient that multiplies the error (SP - PV)

I.i.

Integral Time

I.i.C

Cool integral Time

It is the integral time value, that specifies the time required by the integral term to generate an output equivalent to the proportional term. When Off the integral term is not included in the control algorithm.

D.d.

Derivative Time

D.d.C

Cool Derivative Time

It is the time required by the proportional term P to reach the level of D. When Off it is not included.

O.C.


Overshoot control

(Automatically disabled when the adaptive tune is running) This parameter specifies the span of action of the overshoot control. Setting lower values (1.00→0.01) the overshoot generated by a Setpoint change is reduced. The overshoot control doesn't affect the effectiveness of the PID algorithm. Setting 1, the overshoot control is disabled.



Manual reset

This term specifies the value of the control output when PV = SP, in a PD only algorithm (lack of the Integral term).



Error Dead Band

This term specifies the value of the control output when PV = SP, in a PD only algorithm (lack of the Integral term).

4.5.4 Tuning menu

(not shown for ON-OFF main control output)


See page also 57

Two tuning method are provided:

- Initial one shot Fuzzy-Tuning
- Continuous, self learning Adaptive Tuning


The **Fuzzy-Tuning** determines automatically the best PID term with respect to the process behaviour. The controller provides 2 types of "one shot" tuning algorithm, that are selected automatically according to the process condition when the operation is started.

STEP response



Fuzzy-Tuning is selected when, at the start of the autotune operation, the PV is far from the Setpoint of more than 5% of the span. This method has the big advantage of fast calculation, with a reasonable accuracy in the term calculation.

Natural frequency




Natural frequency is selected when the PV is close to the SP Setpoint. This method has the advantage of a better accuracy in the term calculation with a reasonable speed calculation.

The Fuzzy Tuning determines automatically the best method to use to calculate the PID term, according the process conditions.

The self-learning **adaptive autotune** is not intrusive. It doesn't affect the process, at all, during the phase of calculation of the optimal terms parameters.

Continuous adaptive tune



Continuous adaptive tune is particularly suitable for controlling process whose control characteristics change with time or are not linear in relation to the Setpoint values.

It doesn't require any operation by the user. It is simple and works fine: it samples continuously the process response to the various perturbations, determining the frequency and the amplitude of the signals. On the basis of this data and their statistical values, stored in the instrument, it modifies automatically the PID term parameters.

It is the ideal for all applications where it is required to change continuously the PID terms parameters, in order to adjust the PID to the changes of the process dynamic conditions.

In case of power off with the Adaptive Tune enabled, the values of the PID terms parameters are stored, in order to be reused at the next power on.


At power on the Adaptive Tune starts automatically.

4.5.5 Input menu

EF IL Input filter

Time constant, in seconds, of the RC input filter on the PV input. When this parameter is Off the filter is bypassed.

Filter response



1n.5h Measure Bias


This value is added to the measured PV input value. Its effect is to shift the whole PV scale of its value (± 60 digits).

E.52n Sampling Time

Sampling time, in seconds, of the instrument. This parameter is normally used when controlling slow process, increasing the sampling time from 0.1... 10 s.

4.5.6 Output menu

OP.h4 Control output hysteresis



The parameter can be set between zero and 5% of the configured Span and set in Engineering units.
e.g. Range = $-200 \dots 600^{\circ}\text{C}$
Span = 800°C
Max. Hyst. = $5\% \cdot 800^{\circ} = 40^{\circ}\text{C}$

E.c. Control output cycle time

E.c. C Cool cycle time

It's the cycle time of the logic control output. The PID control output is provided by the pulse width modulation of the waveform.

OP.L Control Output low limit

It specifies the minimum value of the control output signal. It is applied in manual mode, too.

OP.H Control output high limit

OP.C.H Cool output high limit

It specifies the maximum value the control output can be set. It is applied in manual mode, too.

OP.r Heat output maximum rate

OP.r C Cool output maximum rate


This value, specified in %/seconds, with range from 0.01 to 99.99%/s provides the maximum rate of change of the output. When set to Off this function is disabled.

SE.OP Soft start of the control output

It specifies the value at which the control output is set during the start up phase.

SE.tn Soft start time

This value specifies the time the start up phase lasts. The start up phase starts at power up of the controller.



TR.tn Travel time

It provides the time required to the motor positioner to go from the 0% position to 100%.


TR.h4 Minimum step

It specifies the minimum allowed time t of activation of the output to a motor positioner that produces a sensible effect. It is related to the deadband of the positioner

db.nd Heat/Cool deadband





This parameter specifies the width of the deadband between the Cool and the Heat channel.

Heat / Cool Algorithm



SPL.t Split Range % (split range only)


The value set as $SPL.t$ represents the percent of PID output managed by the main output (OP1 or OP5). The balance to 100% is managed by the secondary output (OP2 or OP6).



E.g.: $ENTY - SPL1$
 $ncOP = 4...20$ (OP5)
 $scOP = 4...20$ (OP6)
 $SPLt = 30\%$

OP5: 4 mA = 0% (PID output)
 20 mA = 30% (PID output)

OP6: 4 mA = 30% (PID output)
 20 mA = 100% (PID output)



SPL.2 Split Range Control action (split range only)

This parameter specifies the control action (direct or reverse) of the single action split range modes. See table 5 at page 27:

$ENTY = SPL1...SPL4$

4.5.7 Serial communication menu (option)

Add.S SLAVE address communication - 1...247

Add.P SLAVE Profibus DP address - 3...124

All the instrument connected to the same supervisor must have different addresses. If set Off the serial comm.s is not active.

bdr.S SLAVE Baud rate
bdr.M MASTER Baud rate

It provides the baud rate in the range from 1200 to 19200 bit/s

PAR.y Parity

May be set even $Even$ or odd odd einstellbar. If $none$ is set, parity will be excluded.

Three serial comm.s options are available:


A - Modbus/Jbus SLAVE

The parameters value can be read and when possible modified.

B - Modbus/Jbus MASTER

with Mathematical package
 Mathematical package The transmission and inquiry of parameters value to all the devices using Modbus/Jbus SLAVE (e.g. PLC, etc.) is allowed.

The mathematical package can manipulate the received data by means the serial comm.s.



Example:

The MASTER (X5) reads the process variable from SLAVE 1 (C1) and SLAVE 2 (X3). It compares the two values and send the higher to the SLAVE 3 (PLC).

The available math. operations are:

+ - * / > <

To define the controller operations of this option, the configuration software must be used (1).


C - Profibus DP slave

(Process Field bus protocol)

Industrial standard for peripheral devices connection to a machine in a plant. The protocol installed in this controller, offers the following advantages against the standard normally supplied by other suppliers:

- Communications baudrate **Up to 12 Mb/s with electric isolation.**
- The list of data transfer (profile file) is user configurable. It can be set by means the configuration software (1)

4.6 Parameterisation - Access menu - password - calibration



With the access level Edit, the user defines which groups and parameters are accessible to the operator.


After selecting and confirming the access level Edit, enter in the parameters menu. The code of the access level is displayed on the front panel. Press the and keys to select the proper level.

Group of parameters	Code	Access level
	rEd	Visible
	HidE	Not visible
Group of parameters	Code	Access level
	AlEr	Visible and changeable
	F35t	Included in "Fast view"
	rEd	Visible only
	HidE	Not visible and not changeable

The parameters in the access level *F35t* are recalled on the front panel through the procedure of fast parameter access illustrated in par. 5.2 page 53. The maximum number of fast parameters is 10.


At the end of the parameter list of the selected group, the controller quits from the Edit access level. **Therefore, the Edit level must be selected for each group of parameters.**

The access level of groups and parameters, is activated through



5 Displays

5.1 Standard display



5.2 Fast view (fast access to the parameters)

With this procedure, simple and fast, up to 10 parameters, selected through the fast view (see par 4.6 page 50) are displayed and can be modified by the operator without requiring the standard parameter setting procedure. Press in order to modify the parameters. The value is entered by pressing key.

On left side, please find as an example a list of parameters on Fast view menu.

Commands to the controller and operating phases




6.1 KEYPAD
see page 55

6.2 DIGITAL INPUTS
see page 58

6.3 SERIAL COMMUNICATIONS
see the manual on this topic


- Setpoint modification
- Manual mode
- Local/remote selection
- Stored Setpoint display
- Tune Run / Stop
- Program start/stop (see page 66)



6.1 Keypad commands

6.1.1 Setpoint modification

The Setpoint is directly modified with the keys. Once entered, the new value is checked and becomes operating after 2 seconds. The end of this phase is flagged by flashing momentarily the display with SP




Operator mode
Example of Setpoint modification from 275.0 to 350.0




Modified setpoint value

after 2 seconds




Flash momentarily the SP value to confirm that it has become operating. Back to the operator mode

6.1.2 Auto/Manual mode



Select manual green **MAN** led on



Operator mode (automatic)


Modification of control output value
The new value is immediately working without any confirm.



Modify the output value


Back to the operator mode

The bumpless action is present switching between AUTO, MAN and vice versa.




In case of power failure, the AUTO/MAN status and the output value remain stored in the controller memory.

6.1.3 Local/remote selection



6.1.4 Stored setpoints selection



Der Sollwert kann direkt durch Betätigung der Tasten and verändert werden. Bei der Änderung des Sollwerts wird der neue Wert aktiv, nachdem für 2 Sekunden keine Taste betätigt wurde. Zur Bestätigung blinkt die Sollwertanzeige einmal.



6.1.5 tune run/stop

This controller is provided with 2 different Tuning algorithm:

- Fuzzy tune (one shot tune) for calculating the optimal PID terms parameters
- Adaptive Tune (continuous tune) for a continuous calculation of the PID terms parameters.



6.2 Digital inputs commands

A function is assigned, through the configuration procedure to each IL1, IL3 and IL3 digital input. (see the parameters setting at tab. 10 at page 30).

The configured function is activated when the digital input (free voltage contact or open collector output) is in the On state (closed). It is deactivated by setting the input to the Off state (open).

The activation of the function through the digital input has the highest priority than through the keypad or through the serial communication.

6.2.1 Sollwert-bezogene Funktionen der digitale Eingänge

Function	Parameter value	Performed operation		Notes
		Off	On	
None	OFF	—	—	Not used
Set manual mode	ANdn	Automatic	Manual	
Keyboard lock	EEP.1	Unlock	Locked	With the keypad locked the commands from digital inputs and serial communications are still operating
PV measure hold	HPU	Normal operation	PV is hold	The value of PV is "frozen" at the time the digital input goes to the close state
Setpoint slopes inhibition	SLo.1	Rate limiting is active	Normal operation	When the input is in the on state, the Setpoint is changed in steps
Output forcing mode	F.OuT	Normal output	Forced output	With ON command the output is equal to the forced value (see page 28)
1st stored Setpoint	S.P. 1	Local	1st SP	The permanent closure forces the chosen stored value. Setpoint modification is not possible.
2nd stored Setpoint	S.P. 2	Local	2nd SP	The impulsive closure, selects the stored value. Setpoint modification is allowed.
3th stored Setpoint	S.P. 3	Local	3th SP	If more than one digital input is selecting a Setpoint, the last to be activated is the operating one (see page 43)
Set Remote mode	L-r	Local	Remote	
Reactivation of Blocking	BLcE	—	Blocking Reactivation	The blocking function is activated on closing the command from digital inputs
Alarm Acknowledge	AcE	—	Alarm Acknowledge	The Alarms are acknowledged as soon as the digital input is closed
Alarmquittierung	AcE	—	Alarm Acknowledge	The Alarms are acknowledged as soon as the digital input is closed

7 Programmed setpoint

Introducion

When the Setpoint programmer option (only RE 3073) is present, up to four programs are available.

Main characteristics


- 4 program, 16 segments max/ program
- start, stop, hold etc, commands from the keypad
- time base in seconds, minutes or hours
- continuous or up to 1...9999 time cycling of the program
- two digital outputs (OP3 and OP4) related to the program.
- setting of the maximum allowed deviation from the Setpoint

7.1 Program structure

The program consists of a sequence of segments.

For each segment, it is specified:

- the Setpoint to reach $S.P.$
 - the duration of the segment t_{i-}
 - the state of the OP3 output
- always vorhanden



The program consists of:

- 1 initial segment named I
- 1 end segment named F
- 1...14 normal segments

Initial segment - I


Its main purpose is to define the value the process variable has to maintain before starting the program.

End segment - F


Its main purpose is to define the value the process variable has to maintain at the end of the program and until further changes of Setpoint.

Normal segments - - - -


These segments build up the profile program. There are 3 types of segments:



Dwell




Step



$S.P.$ = Target Setpoint
 t_{i-} = Duration
 - - - = Previous segment
 — = Current segmente
 — = Next segment

Example of setpoint profile




7.2 Setpoint programmer


7.2.1 Maximum allowed deviation (band)

If the PV controlled input value exceeds the band, centred around the SP, the segment time is extended of the same time the PV input stays out of the band. The band width is defined in a parameter of the program segment. The actual segment period is calculated as $t_{i-1} + T_i$

A. Ramp



B. Dwell




7.2.2 Re-start of a program after a power failer

The Parameter `Fail` specifies the behaviour of the programmer at power up (see page 62). Selected between the following 3 choices:



- `Cont` Continue
- `RES` Reset
- `ramp` Ramp

If `Cont` is selected, the execution of the program starts from the point reached at the power failure time. **All the parameters, like Setpoint and the remaining time are restored at the values they had at power off.**




If `RES` is selected, at power on the program ends and goes back to local mode.


If `ramp` is selected, the execution of the program starts from the point reached at the power failure time. **In this case, the programs continue with PV reaching SP with a ramp, whose slope corresponds to the one of the segment running at the power off.**



7.3 Parameterisation – program menu (option)




[1] Two digital outputs are provided to be configured for program purposes. These outputs are usually OP3 and OP4. If this functionality is not required, it can be inhibited by setting OFF the corresponding parameter.



7.4 Program status displaying

The function mode of the program as well its status is displayed clearly by means the **RUN** and **HLD** ; leds as follows:

Function	Status	Led	
		RUN	HLD
Local	Reset	OFF	OFF
Program run	Run	ON	OFF
Program hold	Hold	ON	ON
Program hold for PV outside Error band	Hold back	ON	ON
Program end (reset)	End	ON	OFF



On program run mode, each 3 s the display shows alternatively:

- number of running program;
- number of operating segment as well its status.

The control output value can be displayed during the program run using the procedure at page 53.


P3	Number of running Program (program No. 3)
	each 3 s Operating segment and its status
122	(Segment No.12) - ramp up
124	(Segment No.12) - ramp down
123	(Segment No.12) - dwell
F:	(End segment) Program end

7.5 Start/stop of a program

The various commands, supported by the controller, are different for each of the following operating phases:


- A) when in Local Setpoint mode
- B) during the execution of a program
- C) when the program is in hold

Commands supported by the controllers




The different phase are displayed in a chained way, just for easing the understanding of the functionality. Two different mode for starting and stopping a program are provided: direct mode with the ***** key (see page 66) through the parameter menu (see page 67)

7.5.1 Start/stop of a program by direct mode with *





Note: To reset the program see procedure at page 67

7.5.2 Start/hold/stop of a program through the parameter menu



7.5.3 Digital input commands for setpoint programmer function (option)

Function	Parameter value	Performed operation		Notes
		 Off	 On	
None	OFF	—	—	Not used
Set manual mode	ANZn	Automatic	Manual	
Keyboard lock	EEP.1	Unlock	Locked	With the keypad locked the commands from digital inputs and serial communications are still operating
PV measure hold	HPU	Normal operation	PV is hold	The value of PV is "frozen" at the time the digital input goes to the close state
Setpoint slopes inhibition	SLa.1	Rate limiting is active	Normal operation	When the input is in the on state, the Setpoint is changed in steps
Output forcing	FOut	Normal operation	Forced output value	Digital input ON means activation forcing output value (see page 28)
1 st Program selection	Pr9.1	Local	1 st program	Program selection by permanent closure of the digital input
2 nd Program selection	Pr9.2	Local	2 nd program	
3 rd Program selection	Pr9.3	Local	3 rd program	
4 th Program selection	Pr9.4	Local	4 th program	
Program Start/Hold	r.-H.	HOLD	RUN	When the input is in the On state, the program is executed up to the end. When off, the program is forced in hold.
Program reset	rSt	Normal operation	Program reset	Digital input ON means program reset and control switching to Local setpoint
Deactivation of blocking	BLcE	—	Reactivation of blocking	The blocking function is activated at the time the digital input goes to the close state
Nächstes Segment	nPHt	—	Skips to the next segment	The program skips to the next segment of the program at the time the digital input goes to the close state

8 Technical specification

Features at 25°C env. temp.	Description		
Total configurability (see chapter 4.3, page 23)	From keypad or serial communication the user selects:	- the type of Setpoint - the type of control algorithm - the type of input	- the type and functionality of the alarms - control parameter values - access levels
	Common characteristics	A/D converter with resolution of 160000 points Update measurement time: 50 ms Sampling time: 0.1... 10.0 s Configurable Input shift: -60... +60 digit Input filter with enable/disable: 0.1... 99.9 seconds	
Accuracy	0.25% ±1 digits for temperature sensors 0.1% ±1 digits (for mV and mA)		Between 100...240Vac the error is minimal
Resistance thermometer (for ΔT: R1+R2 must be <320Ω)	Pt100Ω a 0°C (IEC 751) °C/°F selectable	2 or 3 wires connection Burnout (with any combination)	Max. wire Res: 20Ω max. (3 wires) Input drift: 0.1°C/10° T _{env} <0.1°C/10Ω Wire Res.
Thermocouple	L, J, T, K, S, R, B, N, E, W3, W5 (IEC 584) R _j >10MΩ °C/°F selectable	Internal cold junction compensation con NTC Error 1°C/20°C ±0.5°C Burnout	Line: 150Ω max. Input drift: <2μV/°C. T _{env} . <5μV/10Ω Wire Res.
DC input (current)	4... 20mA, 0... 20mA R _j =30Ω	Burnout. Engineering units conf. decimal point position with or without √	Input drift: <0.1%/20°C T _{env} . <5μV/10Ω Wire Res.
DC input (voltage)	0... 50mV, 0... 300mV R _j >10MΩ 1... 5, 0... 5, 0... 10V R _j >10kΩ	Init. Scale -999... 9999 Full Scale -999... 9999 (min. range of 100 digits)	
Frequency (option) 0... 2.0/0... 20.0kHz	Low level ≤2V High level 4... 24V		
PV Input (see chapter 11,12 and page 26)			


Features at 25°C env. temp.	Description									
Auxiliary inputs	Remote Setpoint Not isolated accuracy 0.1%	Current: 0/4...20mA: Rj = 30Ω		Bias in engineering units and ± range						
		Voltage: 1... 5, 0... 5, 0... 10V: Rj = 300kΩ		Ratio: -9.99... +99.99 Local + Remote Setpoint						
	Potentiometer	100Ω... 10kΩ		Feedback valve position						
Digital inputs 3 logic	The closure of the external contact produces any of the following actions: Auto/Man mode change, Local/Remote Setpoint mode change, 3 Stored Setpoint activation, keyboard lock, measure hold, slope inhibit and output forcing Program Hold/Run (if option installed), Program Selection and Skip to Next Segment									
Operating mode and Outputs	1 single, split range or double action PID loop or ON/OFF with 1, 2,3 or 4 alarms	Control output		Alarm AL1	Alarm AL2	Alarm AL3	Alarm AL4	Retransmission PV / SP		
		Single action	Main	Secondary						
			OP1 Relay/Triac			OP2 Relay/Triac	OP3 Relay/Triac	OP4 Relay/Triac	OP5 Analog./Digital	OP6 Analog./Digital
		Split range	OP5 Analog./Digital	OP6 Analog./Digital	OP1 Relay/Triac	OP2 Relay/Triac	OP3 Relay/Triac	OP4 Relay/Triac		
			OP1 Relay/Triac	OP2 Relay/Triac			OP3 Relay/Triac	OP4 Relay/Triac	OP5 Analog./Digital	OP6 Analog./Digital
		Double action Heat/Cool	OP1 Relay/Triac	OP5 Analog./Digital		OP2 Relay/Triac	OP3 Relay/Triac	OP4 Relay/Triac		OP6 Analog./Digital
			OP5 Analog./Digital	OP2 Relay/Triac	OP1 Relay/Triac		OP3 Relay/Triac	OP4 Relay/Triac		OP6 Analog./Digital
			OP5 Analog./Digital	OP6 Analog./Digital	OP1 Relay/Triac	OP2 Relay/Triac	OP3 Relay/Triac	OP4 Relay/Triac		
		Valve drive	OP1 Relay/Triac	OP2 Relay/Triac			OP3 Relay/Triac	OP4 Relay/Triac	OP5 Analog./Digital	OP6 Analog./Digital

Features at 25°C env. temp.	Description	
Control mode	Algorithm	PID with overshoot control/ON-OFF - PID with valve drive algorithm, for controlling motorised positioners
	Proportional band (P)	0.5...999.9%
	Integral time (I)	1...9999 s
	Derivative time (D)	0.1...999.9 s
	Error dead band	0.1...10.0 digit
	Overshoot control	0.01...1.00
	Manual reset	0...100%
	Cycle time (Time proportional only)	0.2...100.0 s
	Min./Max output limits	0...100% separately adjustable
	Control output rate limit	0.01...99.99%/s
	Soft-start output value	1...100% - Time 1...9999 s
	Output safety value	-100...100%
	Control output forcing value	-100...100%
	Control output hysteresis	0...5% Span in engineering units
	Dead band	0.0...5.0%
Cool proportional band (P)	0.5...999.9%	
Cool integral time (I)	1...9999 s	
Cool derivative time (D)	0.1...999.9 s	
Cool cycle time (Time proportional only)	0.2...100.0 s	
Control output high limit	0...100%	
Cool output max. rate	0.01...99.99%/s	
Motor travel time	15...600 s	
Motor minimum step	to 0.1...5.0%	
Feedback potentiometer	100Ω ... 10kΩ	


Features at 25°C env. temp.	Description		
OP1-OP2 outputs	SPST Relay N.O., 2A/250Vac (4A/120Vac) for resistive load Triac, 1A/250Vac for resistive load		
OP3 output	SPDT relay N.O., 2A/250Vac (4A/120Vac) for resistive load		
OP4 output	SPST relay N.O. 2A/250Vac (4A/120Vac) for resistive load		
Analogue/digital OP5 and OP6 (option) outputs	Control or PV/SP/OP retransmission	Galvanic isolation: 500 Vac/1 min Short circuit protected Resolution: 12 bit Accuracy: 0.1 %	
		Analogue: 0/1... 5V, 0...10V, 500Ω/20mA max., 0/4... 20mA, 750Ω/15V max. Digital: 0/24Vdc ±10%; 30mA max. for solid state relay	
	Hysteresis 0...5% Span in engineering units		
AL1 - AL2 - AL3 - AL4 alarms	Action	Active high	Deviation threshold ±range
		Active low	Band threshold 0... range
	Special functions	Sensor break, heater break alarm	
		Acknowledge (latching), activation inhibit (blocking) Connected to Timer or program (if options installed) (only OP3-OP4)	
Setpoint	Local + 3 memorised		Up and down ramps 0.1...999.9 digit/min or digit/hour (OFF=0) Low limit: from low range to high limit High limit: from low limit to high range
	Remote only		
	Local and Remote		
	Local with trim		
	Remote with trim		
	Programmable	If option installed	

Features at 25°C env. temp.	Description	
Programmable Setpoint (optional)	4 programs, 16 segments (1 initial and 1 end) From 1 to 9999 cycles or continuous cycling (DF F) Time values in seconds, minutes and hours Start, stop, hold, etc. activated from the keypad, digital input and serial communications	
Tuning	Fuzzy-Tuning type . The controller selects automatically the best method according to the process conditions	Step response Natural frequency
Auto/Man station	Adaptive Tune self-learning, not intrusive, analysis of the process response to perturbations and continuously calculation of the PID parameters Standard with bumpless function, by keypad, digital input or serial communications	
Serial comm. (option)	RS485 isolated, SLAVE Modbus/Jbus protocol, 1200, 2400, 4800, 9600, 19.200 bit/s, 3 wires RS485 isolated, MASTER Modbus/Jbus protocol, 1200, 2400, 4800, 9600, 19.200 bit/s, 3 wires RS485 asynchronous/isolated, PROFIBUS DP protocol, from 9600 bit/s at 12MB/s selectable, max. length 100m (at 12 Mb/s)	
Auxiliary Supply	+24Vdc ± 20% 30mA max. - for external transmitter supply	
Operational safety	Measure input	Detection of out of range, short circuit or sensor break with automatic activation of the safety strategies and alerts on display
	Control output	Safety and forcing value -100...100% separately adjustable
	Parameters	Parameter and configuration data are stored in a non volatile memory for an unlimited time
	Access protection	Password to access the configuration and parameters data - Fast view
General characteristics	Power supply (PTC protected)	100... 240Vac (-15% +10%) 50/60Hz or 24Vac (-15% +25%) 50/60Hz and 24Vdc (-15% +25%)
	Safety	Compliance to EN61010-1 (IEC 1010-1), installation class 2 (2500V) pollution class 2, instrument class II
	Electromagnetic compatibility	Compliance to the CE standards (see page 2)
	UL and cUL Approval	File 176452
	Protection EN60529 (IEC 529)	IP65 front panel
Dimensions	1/8 DIN - 48 x 96, depth 110 mm, weight 380 g max.	


9. Wiring diagrams – 3172_ST5112




9. Wiring diagrams – 3172_ST5113




9. Wiring diagrams – 3172_ST5113_07




9. Wiring diagrams – 3172_ST5114




9. Wiring diagrams – 3172_ST5114_07




9. Wiring diagrams – 3172_ST5106




9. Wiring diagrams – 3472_ST5112




9. Wiring diagrams – 3472_ST5113




9. Wiring diagrams – 3472_ST5113_07




9. Wiring diagrams – 3472_ST5114




9. Wiring diagrams – 3472_ST5114_07




9. Wiring diagrams – 3472_ST5106



9. Wiring diagrams – 3672_PV61xx



9. Wiring diagrams – 3972_PV61xx



Technische Änderung vorbehalten / Subject to technical alteration / Sous réserve de modifications techniques

